



## USER MANUAL

# S17



ENGLISH

### S17 RECHARGEABLE SPEAKER

#### User's Guide

*Thank you for purchasing S17 Blackpoint's Rechargeable Speaker.*

*Please read the manual carefully before operating.*

#### FEATURES

- Wireless BT connection
- TWS-True Wireless Stereo
- Led light
- FM radio
- USB/TF card
- Rechargeable battery
- Microphone input
- 5W power output

#### SPECIFICATIONS

- Subwoofer Unit: 4"
- AUX in
- Lithium battery: 1200mAH

#### 1. WIRELESS BT CONNECTION

- A)** BT Version: 5.0, with lower power consumption and over 10m meters operating range.
- B)** ON/OFF, after the power is turned on, the display "BLUE" flashes and the speaker emits a BT mode tone.
- C)** Open the phone BT, search for the device name, click the device name to confirm and then connect. After the connection is successful, BT is always on, and the speaker sends a pairing success tone.

#### 2. TF/MICRO SD CARD MODE:

When the speaker is not plugged into the TF card device, it will boot into the BT mode. Inserting the TF card speaker will automatically detect the TF card playback mode. If the speaker has a TF card device, it will enter the TF card mode directly after booting.

#### 3. USB MODE:

- A)** When the speaker is not plugged into the USB disk, it will boot into the BT mode. Inserting the U disk, speaker will automatically detect the USB playback mode, displaying 'PLAY' and playback time. If the speaker has a USB disk, it will enter the TF card mode directly after booting.
- B)** The display shows the playback time during playback, and "PAUSE" character are displayed when paused.

ENGLISH

#### 4. FM MODE:

- A)** Press the button 'MODE', enter into FM mode. FM Frequency is 87.5Hz — 108.0MHz.
- B)** This speaker has a built-in radio antenna, needn't an external antenna.
- C)** Press and hold the button 'PLAY/PAUSE' to automatically search the station, press the "PLAY/PAUSE" button to pause.

#### 5. AUX MODE:

- A)** Plug one end of the 3.5MM audio cable into the speaker AUX jack, the speaker will automatically detect the AUX mode, and the other 3.5MM plug is connected to the phone or computer.
- B)** The "LINE" character is displayed in AUX mode. Press the "PLAY/PAUSE" button to pause.

#### 6. MIC FUNCTION:

- A)** In the power-on mode, plug in the wired microphone, begin to work.  
(Note: turn on the button of wired microphone before using.)

#### 7. CHARGING:

- A)** Plug the USB cable into the speaker to connect to the 5V charger or computer to charge for inside Li-battery.
- B)** The item has a red light on the charging indicator. When charging, the indicator light is on. When it is

ENGLISH

full, the indicator light is off.

#### 8. LOW-POWER PROTECTION:

When the speaker detects that the built-in battery voltage is lower than 3.3V, it will emit a low-power alarm sound. When the battery voltage is lower than 3.1V, the speaker will automatically shut down.

#### 9. MODE CYCLE:

Press 'MODE' button to switch USB, TF, FM, AUx. (Note: USB, TF, AUX are only displayed when USB, TF, AUX input device is plugged in.)

#### 10. TWS (TRUE WIRELESS STEREO)

Use your mobile phone connect one BT speaker successfully firstly, Under BT mode, double click PLAY/PAUSE button of another BT speaker to enter into TWS pairing.

ENGLISH

#### INTERNATIONAL WARRANTY

*Terms and Conditions*

- Blackpoint warrants the operation of this product to be free from any manufacturing and/or material defect for a period of 6 months from the date of purchase by the user.
- This warranty is limited to the repair and/or replacement of this product, according to our own criterion, free of charge within the stipulated term and it does not extend to consequential or incidental damages to other products that may be used with this unit.
- The warranty shall be voided in the following cases: a) repair or attempt to repair by third parties not authorized by the company. b) in case of performing any type of cut in connection cables, plugs, connectors, or other adapters different from the original ones provided by the company.
- To make this warranty effective, you shall contact the Authorized Service Center of your country and they shall carry out the pertinent procedure. In order to start the necessary procedure to get said warranty, you shall hand in the Original Purchase Invoice where the purchase date, dealer name and product identification shall be stated clearly.
- Transportation, freight, stay and/or insurance expenses, if any, are not covered by this warranty.

#### REPAIR SERVICE

To ask for customer service please call **0810-888-7262**.

ENGLISH

[www.blackpoint.life](http://www.blackpoint.life)



MANUAL DE USUARIO

# S17



ESPAÑOL

## PARLANTE RECARGABLE S17

### Guía de usuario

Gracias por comprar el Parlante recargable S17 de Blackpoint.

Por favor, lea el manual cuidadosamente antes de operar.

### CARACTERÍSTICAS

Conexión inalámbrica BT

TWS-Estéreo Inalámbrico Real

Luz led

Radio FM

USB / tarjeta TF

Batería recargable

Entrada para micrófono

5W potencia de salida

### ESPECIFICACIONES

Subwoofer Unit: 4"

Entrada AUX

Batería de litio: 1200mAh

### 1. CONEXIÓN INALÁMBRICA BT

**A)** Versión BT: 5.0, con menor consumo de energía y más de 10 metros de alcance operativo.

**B)** ON/OFF, después de encender la alimentación, el parlante emite un tono de modo BT.

**C)** Abre el teléfono, busca el nombre del dispositivo, haz clic en el nombre del dispositivo para confirmar y luego conéctate. Después de que la conexión se realiza correctamente, BT siempre está activado y el parlante envía un tono de éxito de conexión.

### 2. MODO DE TARJETA TF/MICRO SD

Cuando no está enchufado el dispositivo de la tarjeta TF, se iniciará en el modo BT. Al insertar la tarjeta TF, se detectará automáticamente el modo de reproducción TF. Si el parlante tiene un dispositivo de tarjeta TF, ingresará al modo de tarjeta TF directamente después del arranque.

### 3. MODO USB:

Cuando el parlante no tiene conectado un disco USB, se iniciará en el modo BT. Al insertar el disco USB, el parlante detectará automáticamente el modo de reproducción USB. Si el parlante tiene un disco USB, ingresará al modo USB directamente después del arranque.

### 4. MODO DE FM:

**A)** Presione el botón "MODO", ingrese al modo FM. La frecuencia de FM es 87.5Hz - 108.0MHz.

ESPAÑOL

**B)** Este parlante tiene una antena de radio incorporada, no necesita una antena externa.

**C)** Mantenga presionado el botón "REPRODUCIR/PAUSAR" para buscar automáticamente la estación, presione el botón "REPRODUCIR / PAUSAR" para pausar.

### 5. MODO AUX:

**A)** Conecte un extremo del cable de audio de 3.5MM en el conector AUX del parlante, el parlante detectará automáticamente el modo AUX y el otro conector de 3.5MM se conecta al teléfono o computadora.

**B)** Presione el botón "PLAY / PAUSE" para pausar.

### 6. FUNCIÓN MIC:

**A)** En el modo de encendido, conecte el micrófono con cable. (Nota: active el botón del micrófono con cable antes de usarlo).

### 7.CARGA:

**A)** Enchufe el cable USB en el parlante para conectarlo al cargador de 5V o la computadora para cargar la batería interna de litio.

**B)** El equipo tiene una luz roja en el indicador de carga. Al cargar, la luz indicadora está encendida. Cuando está completa, la luz indicadora se apaga.

### 8. PROTECCIÓN DE BAJA POTENCIA:

Cuando el parlante detecta que el voltaje de la batería

ESPAÑOL

incorporada es inferior a 3,3 V, emitirá un sonido de alarma de baja potencia. Cuando el voltaje de la batería es inferior a 3.1V, el parlante se apagará automáticamente.

### 9. CICLO DE MODOS:

Presione el botón "MODE" para cambiar USB, TF, FM, AUX. (Nota: USB, TF, AUX solo se muestran cuando el dispositivo de entrada USB, TF, AUX está enchufado).

### 10.TWS (ESTÉREO INALÁMBRICO REAL)

Use su teléfono móvil para conectar un parlante BT con éxito en primer lugar. En el modo BT, haga doble clic en el botón Reproducir/Pausa de otro parlante BT para ingresar al modo TWS.

ESPAÑOL

### GARANTÍA INTERNACIONAL

*Términos y Condiciones*

1. Blackpoint garantiza el funcionamiento de este producto ante cualquier defecto de fabricación y/o vicio de material por el término de 6 meses contado a partir de la fecha de compra por parte del usuario.

2. Esta garantía se limita a la reparación y/o reemplazo de este producto, a nuestro criterio, sin cargo alguno dentro del plazo de vigencia y no se extiende a daños consecuentes o incidentales hacia otros productos que fueran utilizados con esta unidad.

3. La garantía queda anulada ante: a) reparación o intento de reparación por terceros no autorizados por la compañía. b) en el caso de realizar cualquier tipo de corte de los cables de conexión, fichas, conectores, u otros adaptadores distintos de los originales de fábrica.

4. Para hacer valer esta garantía se deberá remitir al centro de servicio de post-venta de su país quienes gestionarán la misma. Para gestionar dicha garantía deberá presentar la Factura Original de compra en la cual deberá constar claramente la fecha de compra, nombre del comercio e indentificación del producto.

5. No quedan cubiertos por esta garantía gastos de traslado, flete, estadía, y/o seguro si los hubiera.

ESPAÑOL

### RED DE POST-VENTA

Para consultar por nuestra red de post-venta comunicarse al: **0810-888-7262.**

[www.blackpoint.life](http://www.blackpoint.life)