



BLACK POINT

USER MANUAL

S36.2

S36.2 RECHARGEABLE SPEAKER

User's Guide

*Thank you for purchasing S36.2 Blackpoint's Rechargeable Speaker.
Please read the manual carefully before operating.*

FEATURES


- Wireless BT connection
- TWS-True Wireless Stereo
- Led lights effects
- FM radio
- USB/TF card
- Rechargeable battery
- USB charging cable
- Microphone input
- 10W power output

SPECIFICATIONS

- Subwoofer Unit: 8"
- AUX in
- Lithium battery: 1800mAh

ENGLISH

CONTROL PANEL



1. Power ON/OFF Adjust the master volume.
2. Echo of Microphone Adjustment: Adjust from Min to Max
3. Microphone Volume Knob: Adjust from Min to Max
4. Microphone Input
5. Power Supply: DC 5V 1A
6. AUX IN
7. USB Slot
8. TF Card Slot
9. Mode Button: Toggle between AUX, USB, TF, FM, BT by Short Press; Long Press to turn on/ off the light
10. Previous Track Button: Select previous track
11. Play/Pause Button by Short Press; TWS: TWS function by Long Press;
12. Next Track Button: Select next track
13. Battery Indicator

ENGLISH

DISPLAY SYSTEM SETTINGS

1. Input Mode: When a USB flash drive / TF Card is inserted into the USB/TF input, the unit will automatically switch to USB/TF mode and begin playing Mp3 audio files from the USB flash drive / TF Card
2. Track Number: The track number currently playing from the USB/TF will display.
3. FM Mode: All FM channels display here. Short Press "play/pause" button for auto scan all channels.

WIRELESS BT CONNECTION

BT connection Mode: Open the BT connection of phone. Find the BT connection name of the unit called "S36.2" to connect. After a successful match, you can play the music by speaker.

TWS / TRUE WIRELESS STEREO

- (1) TWS connection: TWS Connection is only for two speakers.
- (2) Turn on the Speakers, press the MODE button to switch to BT connection mode.
- (3) At the first time, please long press each unit's TWS Button for about 3 seconds, then two speakers connected as a pair.
- (4) Connect the phone: Open the phone BT connection settings, Search and Connect the main device BT connection Name 'S36.2'.
- (5) Select music from phone and enjoy TWS playing in pairs with two Speakers.
- (6) Exit TWS: Long press(almost 3 seconds) the TWS button on the device.

ENGLISH

- (7) Re-store factory settings: Select BT connection mode, press and hold the TWS button for about 3 seconds, the device will re-start and there will be no record of previous connection for speaker. The user then connects to other devices according to the above connection steps.

ENGLISH

INTERNATIONAL WARRANTY

Terms and Conditions

1. BLACKPOINT warrants the operation of this product to be free from any manufacturing and/or material defect for a period of 6 months from the date of purchase by the user.
2. This warranty is limited to the repair and/or replacement of this product, according to our own criterion, free of charge within the stipulated term and it does not extend to consequential or incidental damages to other products that may be used with this unit.
3. The warranty shall be voided in the following cases: a) repair or attempt to repair by third parties not authorized by the company. b) in case of performing any type of cut in connection cables, plugs, connectors, or other adapters different from the original ones provided by the company.
4. To make this warranty effective, you shall contact the Authorized Service Center of your country and they shall carry out the pertinent procedure. In order to start the necessary procedure to get said warranty, you shall hand in the Original Purchase Invoice where the purchase date, dealer name and product identification shall be stated clearly.
5. Transportation, freight, stay and/or insurance expenses, if any, are not covered by this warranty.

REPAIR SERVICE

To ask for customer service please call **0810-888-7262**.

ENGLISH



www.blackpoint.life



MANUAL DE USUARIO

S36.2

8"
SUBWOOFER



ESPAÑOL

PARLANTE RECARGABLE S36.2

Guía de usuario

Gracias por comprar el Parlante recargable S36.2 de Blackpoint.

Por favor, lea el manual cuidadosamente antes de operar.


CARACTERÍSTICAS

- Conexión inalámbrica BT
- TWS-Estéreo Inalámbrico Real
- Efecto de luces led
- Radio FM
- USB / tarjeta TF
- Batería recargable
- Cable de carga USB
- Entrada para micrófono
- 10W potencia de salida

ESPECIFICACIONES

- Subwoofer Unit: 8"
- Entrada AUX
- Batería de litio: 1800mAh

PANEL DE CONTROL



ESPAÑOL

- Encendido/apagado Ajuste del volumen principal.
- Ajuste del eco del micrófono: ajuste de mínimo a máximo
- Botón de volumen del micrófono: ajuste de mínimo a máximo
- Entrada de micrófono
- Fuente de alimentación DC
- AUX IN
- Ranura USB
- Ranura para tarjeta TF
- Botón de modo: Alterna entre AUX, USB, TF, FM, BT con una presión corta. Pulsación larga para encender/apagar la luz.
- Botón de pista anterior: Seleccionar pista anterior
- Botón Reproducir/Pausa presionando brevemente; TWS: Función Estéreo Inalámbrico Real con pulsación larga.
- Botón de siguiente pista: selecciona la siguiente pista
- Indicador de batería

AJUSTES DEL SISTEMA DE PANTALLA

- Modo de entrada: cuando se inserta una unidad flash USB / tarjeta TF en la entrada USB / TF, la unidad cambiará automáticamente al modo USB/TF y comenzará a reproducir archivos de audio Mp3 desde la unidad flash USB/tarjeta TF
- Número de pista: se mostrará el número de pista que se reproduce actualmente desde el USB/TF.
- Modo FM: todos los canales FM se muestran aquí. Presione brevemente el botón "reproducir/pausar" para escanear automáticamente todos los canales.

CONEXIÓN INALÁMBRICA BT

Modo de conexión BT: abra la conexión BT del teléfono. Busque el nombre de conexión BT de la unidad llamada "S36.2" para conectar. Después de una conexión exitosa, puede reproducir la música por el parlante.

TWS-ESTÉREO INALÁMBRICO REAL

- Conexión TWS: la conexión TWS es solo para dos parlantes.
- Encienda los parlantes, presione el botón MODE para cambiar al modo de conexión BT.
- La primera vez, presione prolongadamente el botón TWS de cada unidad durante unos 3 segundos, luego los dos parlantes estarán conectados.
- Conecte el teléfono: abra la configuración de conexión BT del teléfono, busque y conecte el dispositivo principal Nombre de la conexión BT 'S36.2'.
- Seleccione la música desde el teléfono y disfrute de TWS tocando en pareja con dos parlantes.

ESPAÑOL

- Salir de TWS: presione prolongadamente (casi 3 segundos) el botón TWS en el dispositivo.
- Restauración de la configuración de fábrica: seleccione el modo de conexión BT, mantenga presionado el botón TWS durante aproximadamente 3 segundos, el dispositivo se reiniciará y no habrá registro de la conexión anterior para el parlante. Se podrá conectar a otros dispositivos de acuerdo con los pasos de conexión anteriores.

ESPAÑOL

GARANTÍA INTERNACIONAL

Términos y Condiciones

- BLACKPOINT garantiza el funcionamiento de este producto ante cualquier defecto de fabricación y/o vicio de material por el término de 6 meses contado a partir de la fecha de compra por parte del usuario.
- Esta garantía se limita a la reparación y/o reemplazo de este producto, a nuestro criterio, sin cargo alguno dentro del plazo de vigencia y no se extiende a daños consecuentes o incidentales hacia otros productos que fueran utilizados con esta unidad.
- La garantía queda anulada ante: a) reparación o intento de reparación por terceros no autorizados por la compañía. b) en el caso de realizar cualquier tipo de corte de los cables de conexión, fichas, conectores, u otros adaptadores distintos de los originales de fábrica.
- Para hacer valer esta garantía se deberá remitir al centro de servicio de post-venta de su país quienes gestionarán la misma. Para gestionar dicha garantía deberá presentar la Factura Original de compra en la cual deberá constar claramente la fecha de compra, nombre del comercio e identificación del producto.
- No quedan cubiertos por esta garantía gastos de traslado, flete, estadia, y/o seguro si los hubiera.

ESPAÑOL

RED DE POST-VENTA

Para consultar por nuestra red de post-venta comunicarse al: **0810-888-7262.**



www.blackpoint.life